

WamBam

Fun Name. Serious Fence.

JIMINY PICKET VINYL GATE (4'H X 4'W)


ASSEMBLY INSTRUCTIONS VG24300

60 MIN

Approximate assembly time

Want to see a video on how to
assemble this product?

Scan the QR code



GENERAL INFORMATION



IMPORTANT

- ⊕ Check the inside of the larger pieces in your box for other materials packed inside.
- ⊕ When assembling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- ⊕ We recommend an area approximately 5'x 8' for unobstructed assembling.
- ⊕ You should not need to use excessive force when assembling components.

MISSING OR DAMAGED PARTS?

VISIT OUR WEBSITE FIRST, SO WE CAN HELP YOU RIGHT AWAY!

Although great care has been taken to ensure proper packaging and handling of this product, occasionally problems occur. If you discover any missing, damaged, or defective parts, please visit our website to order replacement parts. If you experience any further trouble with your product, please contact our customer care department.

 parts.nychbrands.com

 hmmm@wambamfence.com

 **704-892-5222 / 877-778-5733**

Customer service agents are available to take calls weekdays from 9am-5pm EST. If you call outside of business hours, please leave a voicemail.

To help you quickly and accurately, please have reference item number **VG24300** and the specific part name which can be found on page 5. It is helpful if you can provide the batch lot which is a stamped number inside the box.

NEED ASSEMBLY HELP?

Please give us a call at **704-892-5222 / 877-778-5733**.

If you are having problems with the assembly or installation of this product, we are happy to assist you with the process.

NEED TO RETURN?

If for some reason you need to return this product, please allow us to help resolve your issues first. If you still decide to return the product, **you will need to initiate the return from the company you originally purchased from.**

GENERAL INFORMATION

1. Read over fence instructions first.

Your gate and fence will work better together if you first take the time to read and understand your fence.

2. Pre-assemble the gate frame.

Please do not screw the gate frame together until you have temporarily assembled the gate frame. In other words, do a dry run first. This will ensure:

1. That you have everything necessary to complete the gate.
2. That you will have assembled the gate frame in the correct order.
3. All of the pieces fit and function properly.
4. The gate height and width are similar to the measurements shown on page four.


It's easier to troubleshoot when things are not screwed together. After you assemble your gate correctly, please disassemble as necessary, and use the included self-drilling stainless steel screws to permanently assemble the gate.

3. Install your gate posts before your fence posts.



Your fence panels will be more forgiving for a custom fit than your gate. Position and install your gate posts before you do anything else.

4. Do not hang your gate system off a single non-supported post.


Your gate will perform better and last longer if your hinge post is connected to a panel of fence that is connected to another post. This way, the weight strain will be transferred onto two posts versus just one. Installing fence panels on both sides of your gate is ideal in all situations. If this is not possible because of space restrictions, please contact us for alternative solutions.




DETAILED PRODUCT DIMENSIONS AND SPECIFICATIONS



Top Rail













Bottom Rail



Vertical Stile


STEP 1: LAY OUT MATERIALS

<p>A </p> <p>Corner Bracket (2)</p>	<p>B </p> <p>T-Bracket (2)</p>	<p>C </p> <p>Post Cap (2)</p>	<p>M </p> <p>Latch Catch (1)</p>
<p>D </p> <p>Metal Post Stabilizer (1)</p>	<p>E </p> <p>Picket Cap (7)</p>	<p>F </p> <p>Gate Jig (1) 1½" x 3½" x 57¾"</p>	<p>N </p> <p>Latch Finger (1)</p>
<p>G </p> <p>Bottom Rail (1) 1½" x 3½" x 48⅞"</p>	<p>H </p> <p>Top Rail (1) 1½" x 3½" x 48⅞"</p>	<p>I </p> <p>Gate Brace w/ Fasteners (1)</p>	<p>O </p> <p>1¼" White Self-Drilling Stainless Steel Screw (20)</p>
<p>J </p> <p>Vertical Stile (2) 1½" x 3½" x 32⅞"</p>	<p>K </p> <p>Picket (7) ⅞" x 3½" x 43⅞"</p>	<p>L </p> <p>Hinge (2)</p>	<p>P </p> <p>1¼" Black Self-Drilling Stainless Steel Screw (20)</p>
			<p>Q </p> <p>2" Black Self-Drilling Stainless Steel Screw (20)</p>
			<p>R </p> <p>Vinyl Glue (1)</p>
			<p>S </p> <p>2¾" Gate Tension Pin (1)</p>

STEP 2: INSTALL GATE JIG, POST ANCHORS, AND POSTS

STEP 2.1


► Identify the location of your gate. Dig a trench 60" long x 6" wide x 5½" deep.



STEP 2.2


► Identify the location of the Metal Post Stabilizer (D) and pound it into the ground. Temporarily place the anchor positioner into the metal post stabilizer and determine position.

Note: The metal post stabilizer is to be used only on the hinge post.




STEP 2.3

► Place the Gate Jig (F) over the metal post stabilizer.




STEP 2.4

► Place the anchor positioners into the gate jig. The pegs on the bottom of the anchor positioners will insert into both the gate jig and the metal post stabilizer.




STEP 2.5

► Pound your post anchors into place. See fence instructions, if necessary, for more information on how to install anchors. Adjust the leveling donuts and install the posts.




STEP 2.6

► Backfill excavated dirt over the gate jig.



STEP 2.7




▶ Make sure to fasten the fence panels before attaching the gate.

STEP 3: ASSEMBLE THE GATE FRAME BOTTOM AND SIDES


STEP 3.1

▶ Insert the Bottom Rail (G) until it bottoms out inside Corner Bracket (A).




STEP 3.2

▶ Insert the bottom rail until it bottoms out inside the opposite corner bracket.



STEP 3.3



▶ Insert (2) Vertical Stiles (J) into the corner brackets until they hit the bottom rail. Fasten the bottom brackets using (4) 1 1/4" White Self-Drilling Stainless Steel Screws (O).



STEP 4: ASSEMBLE THE GATE FRAME TOP

STEP 4.1 ▶



▶ Insert the Top Rail (H) all the way until it bottoms out inside the T-Bracket (B).



STEP 5: FINISH ASSEMBLING THE GATE FRAME

STEP 5.1 ▶


▶ Slide the gate frame top down over the vertical stiles.



Fully assembled gate frame.

STEP 5.2


► Screw the brackets with (16) 1¼" white self-drilling stainless steel screws as illustrated. The corner-to-corner measurements must be the same to ensure the gate is square and the width of the gate should be 48".



STEP 6: INSERT PICKETS AND ATTACH PICKET AND POST CAPS



STEP 6.1

▶ Insert the Pickets (K), with the tabs at the bottom through the top rail and into the bottom rail.





STEP 6.2

▶ Use the Vinyl Glue (R) to glue the Picket Caps (E) and attach them to the top of the pickets.




STEP 6.3

▶ Glue the Post Caps (C) and attach them to the top of the T-brackets.




Completed gate.



STEP 7: FASTEN HINGES AND GATE LATCH

STEP 7.1 ▶


1. Fasten the Latch Finger (**N**) to the gate brackets with (6) 1¼" Black Self-Drilling Stainless Steel Screws (**P**).
2. Fasten the Hinges (**L**) onto the opposite side of the gate with (12) 1¼" black self-drilling stainless steel screws.



STEP 8: ASSEMBLE AND FASTEN GATE BRACE


STEP 8.1

▶ Assemble the Gate Brace (I) by sliding the larger square tube over the smaller square tube. Align the holes and install by using the included hardware.



STEP 8.2

▶ Double check that the gate is square and then screw the gate brace into place with (4) ½" screws packaged with the gate brace.




STEP 9: ALIGN GATE AND SECURE HINGES TO POST

STEP 9.1

- ▶ Align the gate to the horizontal fence rails.


Note: Both the fence & gate horizontal rail spacing can be adjusted to lower heights.



STEP 9.2A

- ▶ Fasten the hinges to the posts as illustrated.



Note: See the next page for more details.



STEP 9.2B

► **How to position the screws on the post side of the hinge:**
Using a 1/8" drill bit, pre-drill the holes for the hinge screws as illustrated. Angle your drill slightly as illustrated.

Note: Swing the gate open and pre-drill four more holes for the hinge screws as illustrated.




Top View

Note: Angle your drill to pierce into the angled portion of the post as illustrated.


STEP 9.2C

► Fasten (3) 2" black self-drilling stainless steel screws through the drilled holes.



STEP 9.2D


► Fasten (4) 2" black self-drilling stainless steel screws through the drilled holes. Repeat steps 9.2B through 9.2D for the second hinge.



STEP 10: LEVEL GATE AND ADJUST HINGES


STEP 10.1

▶ Using a level, make sure that the gate fits and functions with its latching post.





STEP 10.2

▶ The hinges can be adjusted moderately to bring the gate into level alignment with the post.



STEP 10.3


▶ To set the tension on the gate hinge, insert the 2 3/4" Gate Tension Pin (S) into one of the holes on the hinge and rotate it to release tension on the gate hinge to remove the pin.




STEP 11: INSTALL LATCH CATCH

STEP 11.1 ▶

▶ Align and fasten the Latch Catch (M) with (6) total 1¼" black self-drilling stainless steel screws. The latch catch should be set so that it is aligned with the height of the latch finger.




▶ Congratulations! You did it! Go grab a beverage of your choice, admire your handiwork, and show us what you got by entering our annual photo contest!



ALTERNATIVE APPLICATION: INSTALL OVER A SIDEWALK OR PATH

STEP 1.1 ▶


▶ **Option 1:** If the sidewalk is less than 52", use the gate jig as a temporary spacer. Proceed installing the panels according to the fence's install guide.



ALTERNATIVE APPLICATION: INSTALL OVER A SIDEWALK OR PATH

STEP 1.1 ▶


▶ **Option 2:** If the sidewalk is wider than 52", use surface mounts and follow the instructions included with them. Surface mounts must be purchased separately and can be found by searching product SKU SB61000.



CUSTOMIZE YOUR GATE DESIGN:

Use the cutting guide below to trim your pickets to create a custom gate design.

This gate can also be trimmed down both in width and height to accommodate custom applications.



A	$37\frac{1}{8}"$
B	$40\frac{3}{8}"$
C	$42\frac{3}{8}"$
D	$43\frac{1}{8}"$

Cut down the vertical stiles by 6"

WamBam

Fun Name. Serious Fence.



6935 Reames Rd. Ste. K.
Charlotte, NC 28216



hmmm@wambamfence.com

704-892-5222
877-778-5733



WWW.WAMBAMFENCE.COM